

Empresas: ActiveSync MS Exchange

Configuración ActiveSync para el Apache

Configuración del Active Sync para la descarga y envío de mensajes a través del **Correo de Outlook**.

- Configurar el Servidor, el Nombre del Usuario, la Contraseña y el Dominio.
- Chequear opciones que desea Sincronizar: Contactos, Calendario, Correo, Tareas. Una vez seleccionada las opciones, presionar **Siguiente**.
- Indicará que ha sido completada la instalación de Pocket PC con el Active Sync y hacer click en **Finalizar**.

El equipo comenzará a sincronizarse.

Exchange server credentials
Enter the information that will authenticate you to a server running Microsoft Exchange Server

Server address:

Note: If you use Outlook Web Access, this is the same as your OWA server address.

This server requires an encrypted (SSL) connection

Logon Credentials

User name:

Password:

Domain:

Save password
(required for automatic synchronization)

< Atrás Siguiente > Cancelar

Synchronization Options
Choose the information you want to synchronize with your Pocket PC. For each information type, you can choose the source with which it will synchronize.

Information Type	Source
<input checked="" type="checkbox"/> Contactos	Exchange Server
<input type="checkbox"/> Calendario	Exchange Server
<input type="checkbox"/> Correo	Exchange Server
<input checked="" type="checkbox"/> Tareas	Exchange Server
<input type="checkbox"/> Notes	Windows PC (This PC)
<input type="checkbox"/> Favorites	Windows PC (This PC)
<input type="checkbox"/> Files	Windows PC (This PC)
<input type="checkbox"/> Media	Windows PC (This PC)

Select an information type above and click Settings to change synchronization options for that type.

< Atrás Siguiente > Cancelar